Code 2D CLASSIFICATION CHANGE action's of NASA CR 55236 STATE-OF-N93-72552 Unclas 29/20 TURN **PROPULSION SYSTEMS** (U)

RM 63TMP-22

GENERAL ELECTRIC COMPANY SANTA BARBARA CALIFORNIA

(NASA-CR-55236) STATE-OF-THE-A RELIABILITY ESTIMATE OF SATURN PROPULSION SYSTEMS (GE) 48 p

## STATE-OF-THE-ART RELIABILITY ESTIMATE OF SATURN V PROPULSION SYSTEMS (U)

NOTE: This ocument contain information affecting the stional defence of the United States within the deaning of the Espionage Laws, the 18, USC, Sections 793 and 794. The consmission or the revelation of its contains any manner. revelation of its content in any manner to an unauthorized person prohibited by law.

Robert P. Dill, Project Leader


N. Brown,

R. L. Curtis>

C. R. Herrmann,

CNASA CONTRACE NASW HID) A. Trampus gun. 1963 regs

INASA CR ---RM 63TMP-22 June 1963



GENERAL ELECTRIC COMPANY SANTA BARBARA, CALIFORNIA

3539707


assified





## TABLE OF CONTENTS

| LIST OF IL | LUSTRATIONS  | iii |
|------------|--|-----|
| LIST OF TA | ABLES  | iv  |
| INTRODU    | CTION  | 1   |
| SECTION    |  |     |
| . 1        | PROPULSION SYSTEMS RELIABILITY                               | 3   |
| II         | COMPONENT RELIABILITY DATA                                   | 5   |
| 111        | FAILURE ANALYSIS RESULTS                                     | 11  |
| IV         | SUMMARY OF RELIABILITY ESTIMATES                             | 35  |
|            | State-of-Art Reliability Estimate                            | 35  |
|            | Saturn V Propulsion System Reliability Estimate Calculations | 36  |
| LIST OF S  | YMBOLS   | 40  |
| REFERENC   | ES   | 42  |
| BIBLIOGR   | APHY   | 43  |





## LIST OF ILLUSTRATIONS

| FIGURE NO. | TITLE  | PAGE |
|------------|--|------|
| 1          | Saturn V vehicle configuration   | 2    |
| 2          | Methodology for establishing system design reliability   | 4    |
| 3          | Block diagram of J-2 propulsion system   | 11   |
| 4          | F-1 engine schematic S-IC stage single engine subsystem  | 13   |
| 5          | S-IC stage fuel system   | 16   |
| 6          | S-IC stage oxidizer system of Saturn V vehicle   | 16   |
| 7          | J-2 engine system schematic  | 19   |
| 8          | S-IC stage control pressure system of Saturn V vehicle   | 25   |
| 9          | S-II stage hydraulic system  | 27   |
| 10         | S-IVB stage hydraulic system   | 29   |
| 11         | Simplified schematic for engine tank and propellant feed system for S-II and S-IVB             | 32   |
| 12         | Reliability curves of S-I and S-II stages, engine cluster with five J-2 engines, four with TVC | 34   |





## LIST OF TABLES

| TABLE NO. | TITLE   | PAGE                             |
|-----------|---|----------------------------------|
| 1         | Objectives and tests of a reliability-engineering program   | 6                                |
| 2         | Propulsion system component reliability estimates   | 8                                |
| 3         | Failure analysis chart, S-IC stage of Saturn V vehicle, F-1 single engine subsystem   | 14                               |
| 4         | Failure analysis chart, S-IC stage of Saturn V vehicle, fuel system   | 17                               |
| 5         | Failure analysis chart, S-IC stage of Saturn V vehicle, oxidizer system   | 18                               |
| 6         | Failure analysis chart(s), J-2 engine system  a) Engine oxidizer subsystem b) Engine fuel subsystem c) Engine gas generator subsystem d) Engine pneumatic control package subsystem e) GH <sub>2</sub> start and tank pressurization subsystem f) Miscellaneous engine subsystems | 20<br>21<br>22<br>22<br>23<br>23 |
| 7         | Failure analysis chart, S-IC stage of Saturn V vehicle, control pressure system   | 26                               |
| 8         | Failure analysis chart, S-II stage of Saturn V vehicle, hydraulic single engine control subsystem   | 28                               |
| 9         | Failure analysis chart, S–IVB stage of Saturn V vehicle, hydraulic single engine control subsystem  | 30                               |
| 10        | Failure analysis chart, S–II and S–IVB stages of Saturn V vehicle, tank and propellant for J–2 engine   | 33                               |





#### INTRODUCTION

This report presents the results of a reliability prediction study of the propulsion systems for the NASA-MSFC Saturn V vehicle shown in Figure 1. The TEMPO method of combining the failure mode of each component of the subsystems being analyzed was used throughout the study. Since most of the configurations of the subsystems examined are presently in the development phase, this prediction is based upon the current available data and should be considered a preliminary estimate only.

This study was performed in collaboration with the ARINC Research Corporation as an adjunct to the reliability prediction studies pertinent to the various stages comprising the Saturn V Launch Vehicle System, and administered by the Apollo Support Department of the General Electric Company.\* The results of TEMPO's specific areas of investigation are presented. These include reliability estimates of the propulsion systems for the S-IC, S-II, and S-IVB stages of the Saturn V vehicle identified in Figure 1.

A review of the flight history of existing ballistic missiles indicates that as the vehicles progress through the developmental flight test program the reliability increases rapidly at first and then approaches an asymptotic value. This asymptotic value of reliability is referred to as "state-of-the-art" reliability, † and it represents the reliability potential after embryonic design failures have been identified in the flight test program and eliminated.



<sup>\*</sup>Performance of this contract was conducted under the technical direction of the Saturn Systems Office of NASA's Marshall Space Flight Center and administered by General Electric Purchase Order No. 036-850150-54081 under NASA Contract NASw-410.

†Designated "state-of-art" reliability throughout the remainder of this report.




Figure 1. Saturn V vehicle configuration





# SECTION I PROPULSION SYSTEMS RELIABILITY

The leveling off of the predicted state-of-art reliability is due, as the name implies, to the limitations in materials, design, manufacturing, and testing within the bounds of the current technology. The methodology used in predicting the state-of-art reliability for this study is based on the use of propulsion systems component data from liquid propellant rocket engines in advanced phases of development. Thus, the state-of-art estimates presented in this report should reflect the reliability potential of the subject systems within the limitations of the present technology. These estimates do not imply a limitation of the subject system reliability to that predicted, but are intended as a guide indicating what reliability level might reasonably be expected of these systems.

This section describes the method used for prediction of the state-of-art reliability of the propulsion systems for the S-IC, S-II, and S-IVB stages of the Saturn V vehicle. The methodology for evaluating system reliability, as illustrated in Figure 2, required a failure or malfunction analysis of each system to establish the components and subsystems which are vital to its successful operation. Such an analysis is essentially an inventory and examination of the components to determine whether their failure will result in a corresponding failure of the system and, if so, the manner in which the system will fail. The malfunction analysis is used to establish a failure network (or failure mode analysis) for the system which permits overall system reliability to be estimated from component reliabilities.

To facilitate the reliability prediction, each propulsion system was divided into functional equipment systems, each of which operates independently of the others and can thus be analyzed separately. These systems are:

- 1. Fuel system (includes tankage and associated plumbing required to deliver fuel to the engine system).
- 2. Oxidizer system (includes tankage and associated plumbing required to deliver oxidizer to the engine system).





- 3. Hydraulic control system (required for engine gimballing).
- 4. Control pressure system (supplies an inert gas at ambient temperature for valve actuation).
- 5. Engine system.

Malfunction and failure mode analyses were performed to determine the reliability of each system. The state-of-art reliability of the propulsion system is obtained from a combination of the reliabilities for all the independent equipment systems.




Figure 2. Methodology for establishing system design reliability



# SECTION II COMPONENT RELIABILITY DATA

State-of-art reliability estimates should be required for each phase of a missile systems' development program, from preliminary design through the operational use of the missile. Table 1 outlines the relationship of the reliability and engineering programs for the four phases of a system development program. In the initial developmental phases the state-of-art estimates are the only estimates that can be made since there is no existing system hardware test data available to allow actual systems reliability to be determined. These state-of-art estimates are then the only known source of reliability information based on actual failure data from which initial design assessments and resource allocations can be made. In the later phases of the development program these state-of-art estimates are combined with reliability estimates of the hardware to aid in the assessment of the program and to indicate critical areas. Failure data indicative of the current technological limitations of the subject system in the actual flight operational environment are required in all the phases in order to prepare the state-of-art estimates. In compiling this state-of-art failure data for propulsion and mechanical system components, the following factors were considered:

- 1. Propulsion system components are operated for only a small fraction of their lifetimes; therefore, operating environment is of greater importance than operating time.
- 2. In general, propulsion systems fail as the result of the failure of a particular component to operate as required in a particular operational mode (e.g., vent valve fails open, vent valve fails closed, pressure switch fails closed, etc.). The reliability assessment of these systems requires failure data that includes an apportionment of the failures between the component operational modes.
- 3. Expected operating environments are difficult to anticipate or simulate. For this reason, the best failure data are obtained from flight test results.



Table 1. Objectives and tests of a reliability-engineering program

|                          | RELIABILITY PROGRAM   | ENGINEERING PROGRAM  |
|--------------------------|---|--|
| PHASE I<br>Objectives:   | Synthesis (malfunction analysis) (1) Early recognition of failure modes and problem areas (2) Permits early recognition of product maturity (3) Evaluation and recommendation of design modifications (4) Test planning | Design (1) System specifications and drawings (2) Test planning  |
| Type of tests:           |   | (1) Feasibility tests  |
| PHASE II<br>Objectives:  | Attainment (1) Identify failure mechanisms (2) Identify failure modes   | Development (1) Establish proper system functioning under limited environment                                  |
| Type of tests:           | (1) Induced malfunction tests (2) Tests-to-failure (limit tests, endurance tests)   | (1) Functional test, limited environment (Qualification and PFRT tests)  |
| PHASE III<br>Objectives: | Demonstration (1) To establish probability that all required failure mechanisms have been located and eliminated  | Operation (1) To obtain proper system functioning under actual environment (includes human factors and flight) |
| Type of tests:           | <ul><li>(1) All type tests provide information</li><li>(2) Confidence tests</li></ul>   | (1) Functional tests—actual environment (Qualification)  |
| PHASE IV<br>Objectives:  | Maintenance (1) To maintain system re- liability throughout the operational use of the system   | Production (1) To obtain proper system functioning under production conditions                                 |
| Type of tests:           |   | (1) Functional tests (acceptance tests) (2) Quality verification tests*  |

<sup>\*</sup>Rocketdyne nomenclature.





Unfortunately, missile flight data cannot be relied upon to supply sufficient information for establishing component reliability values because the number of test flights is small and the monitoring of all components is not feasible. The component data that are available from missile flight programs are primarily maintenance data; that is, tabulations of component failure modes and failure mechanisms which have occurred in the checkout of the missiles. Such data are useful in identifying component failure mechanisms and their relative rates of occurrence, but they do not provide the basis for establishing the frequency of failures under conditions that exist in flight. However, the missile flight programs, while not a source of component failure data, do provide failure data on the major subsystems.

Nearly 10,000 well monitored runs on hot-fire test stands have been made over the past five years on large liquid propellant rocket engines. The environment to which the components are exposed in these firings simulates the actual flight environment. The component failure data from the test stand runs include both maintenance and cutoff failures from engine systems in advance phase of development. During a test maintenance failures may occur that do not necessarily result in premature shutdown, but may necessitate corrective maintenance before a specific test can be performed. Cutoff failures that occur during a test result in premature shutdown and closely represent actual failures in flight. The types of failure represented by the cutoff data are those to be expected from components which are fully developed and which have been properly inspected before use. These cutoff stand components failure data, in conjunction with the missile flight major subsytem failure data, were used to obtain the propulsion system component state-of-art reliability estimates used in this study and presented in Table 2.

To permit the data to be used for computing reliability estimates of components in equipment systems other than the engine system, and to average out the effects of design and environment, the failure rates were organized into generalized groupings of components, such as solenoid-actuated valves, pressure switches, etc. Because of the high reliabilities exhibited by the components and the limited number of tests, the generalized groupings were required, in many instances, to obtain minimal, statistically-significant, reliability estimates.

In order to indicate the relative reliability values of particular vehicle designs, consideration must be given to differences in the manner in which the vehicles are operated. Different modes of operation are particularly apparent in a comparison of: (1) a boost vehicle



Table 2. Propulsion system component reliability estimates (Revised May 1963)

| Reliability of Surface of the control of th                      | LUBNOGWOO  |              | Fails     | Failure Distribution | UO        | 4A*                                      | *APPORTIONED RELIABILITY   | ELIABILITY   |              |
|--|--|--------------|-----------|----------------------|-----------|--|--|--------------|--------------|
| All Failures   |  | Reliability  | Start     | Run *                | (3 sec -) | Failure                                  | 3  | ď            | Shut         |
| Comparison   Com |  | All Failures | (0-3 sec) | Rel.*                | ~         | Mode                                     | The state of the s | UO.          | - A          |
| Longer    1,000   1, | Main Fuel Valve<br>Phen or hyd, actuated)          | 8666         | 8666      | 1.0                  | .00042    | Fail apen<br>Fail alosed                 | 8666   | 2.0          | 5 0.         |
| 10   10   10   10   10   10   10   10  | Main LOX Valve (Pneu, or hyd, actuated)            | 0666         | 9666      | 7666                 | 210.      | fail apen<br>Fail closed                 | 9666°  | 8666         | 8666°        |
| 9996         . 9998         . 9998         . 0060         Fail open         . 9999         . 9999           9999         1.0         . 9999         . 0022         Fail closed         1.0         . 9999           9999         1.0         . 9999         . 0021         Fail closed         1.0         . 9999           9999         1.0         . 9999         . 0021         Fail closed         1.0         . 9999           9991         . 9990         . 9996         . 9992         . 0032         Fail high         . 9996         . 9999           9977         . 9993         . 0030         Fail high         . 9999         . 9999         . 9997         . 0030         Fail high         . 9999         . 9999         . 9997         . 0030         Fail high         . 9999         . 9999         . 9997         . 0030         Fail high         . 9999         . 999   | Pilot or Cantrol Valve<br>(Pneu, or hyd, actuated) | £666         | 3000      | 8666                 | . 0065    | Fail open<br>Fail closed                 | 6666   | 6666         | 6666<br>6666 |
| 1.0  | Solenoid Valve                                     | 9666         | 8666      | 8666                 | 0900`     | Fail open<br>Fail closed                 | 6666°  | 6666<br>6666 | 6666<br>5666 |
| Colored   Colo | Vent or Relief Valve<br>(Spring loaded)            | B666 '       | 1.0       | 8666                 | .0052     | Fail open<br>Fail closed                 | 0  | 6666         | 0.0          |
| tch         -, 9995         1.0         >, 9994         >, 0092         Fail when red 'd.         1.0         9995           tch         -, 9991         , 9996         , 9995         , 013         Fail when red 'd.         , 9998         , 9998           LOX         -, 9978         , 9990         , 9988         , 026         Fail high         , 9998         , 9994           LOX         -, 9973         , 9998         , 9977         , 0399         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998         , 9978         , 9998   | Check Valve  | >. 9999      | 0.1       | 6666 '<              | >, 0021   | Fail closed                              | 0  | 66 1         | 2            |
| reh         Spyel         . 9996         . 9995         . 9996         . 9998   | Servo Valve  | . 5666       | 0.1       | >, 9994              | >.0092    | Fail                                     | 1.0  | 5666.        | C.:          |
| LOX         9978         .026         Fail high         .9995         .9994         .10           Non         10X         .9978         .026         Fail high         .9995         .9994         .10           Cryogenic         .9973         .9997         .9996         .9977         .9996         .9977         .9998         .10           All cryogenic         .9973         .9973         .9976         .9978         .9978         .9978         .10           All cryogenic         .9973         .9995         .9978         .048         All trailures         .9998         .10           All crimes         .9997         .9998         .10         .9999         .9996   | Pressure Switch                                    | 1666         | 9666`     | 5666.                | .013      | Fail when req'd.<br>Open when not req'd. | 8666°  | 8666<br>8666 | 8666         |
| Non Cryogenic         Oppgage  | -  | 8266         | 0666      | 8866                 | .026      | Fail high<br>Fail low                    | . 9995   | 3994         | 0.0          |
| 1  | 1  | £6666 ·      | 2666      | 9666 .               | . 0080    | Fail high<br>Fail low                    | 6666   | 8666         | 0 0.         |
| K    19973   19995   19996   | J.   | 9975         | 8666      | 7766                 | .052      | leak,                                    | 8666   | 77.60        | C.           |
| .9948         .9992         .096         .098         .010         All failures         .772           .9995         1.0         .9996         .0086         All failures         .9992         .9996         .032         All failures         .9999         .9996         .030         All failures         .9999         .9996         .039         .0399         .9996         .039         .0399 <td>Chambers</td> <td>. 9973</td> <td>3666</td> <td>826</td> <td>828</td> <td>Combustion instability</td> <td>9995</td> <td>85,8</td> <td>0 0</td>   | Chambers   | . 9973       | 3666      | 826                  | 828       | Combustion instability                   | 9995   | 85,8         | 0 0          |
| 9995         1.0         .9995         .010         All failures         .9992         .9996         .0086         All failures         .9999         .9996         .9996         .10         .9999         .9996         .10         .9999         .9996         .10         .9997         .10         .10         .9997         .10         .9997         .10         .9997         .10         .9997         .10         .9997         .10         .9997         .10         .9997         .10         .9998         .10         .9998         .10         .9998         .10         .9998         .10         .9998         .10         .9998         .10         .9998         .10         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9999         .9998         .9999         .999   | (60K to 200K)                                      | . 9948       | 7466      | 90,65                | 040       | Ail railores                             |  | 2000         | C            |
| ations         . 9988         . 9992         . 9086         . 0080         All failures         . 7772         . 7772           Ings.         . 9985         . 9997         . 0070         All failures         . 9999         . 9997         . 0070         All failures         . 1.0         . 9997         . 1.0         . 9997         . 1.0         . 9997         . 1.0         . 9997         . 1.0         . 9997         . 1.0         . 9992   | Vernier Thrust Chambers                            | 5666         | 1.0       | 5666                 | 010.      | All foilures                             | 0000   | 4000         | 2 -          |
| Ings. Hardware, etc.         .9995         .9996         .0977         .0070         All failures         .7770         .7770           ings. Hardware, etc.         .9997         1.0         .9997         .0070         All failures         1.0         .9992         1.0           irigs. Hardware, etc.         .9998         1.0         .9998         .0038         All failures         1.0         .9998         1.0           oy 8ox (10 relays)         .9983         .9991         .023         All failures         .9992         .9991         1.3           G. Ignitors         .9995         .9998         .0 <t< td=""><td>Gas Generators</td><td>. 9888</td><td>. 9992</td><td>9666</td><td>9800</td><td>Ail failures</td><td>2,44.</td><td>7000</td><td>-</td></t<>  | Gas Generators                                     | . 9888       | . 9992    | 9666                 | 9800      | Ail failures                             | 2,44.  | 7000         | -            |
| 10         9997         10         9997         0070         All failures         10         9997         10         9992         10         9992         10         9992         10         10         9992         10         10         9992         10         10         9992         10         10         9992         10         10         9992         10         10         9992         10         9992         10         10         9992         10         9992         10         9992         10         9992         10         9992         10         9992         10         9993<  | Тигроритр  | .9985        | 6666      | 9866                 | .032      | All failures                             | 5666   | 0,5          | 2 .          |
| stc.         . 9981         . 9999         . 039         Excessive leakage         . 9999         . 10         . 9988         . 038         All failures         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9998         . 1.0         . 9988 <td>Heat Exchangers</td> <td>. 9997</td> <td>1.0</td> <td>2666</td> <td>0070</td> <td>All failures</td> <td>1.0</td> <td>/666</td> <td>2.</td>  | Heat Exchangers                                    | . 9997       | 1.0       | 2666                 | 0070      | All failures                             | 1.0  | /666         | 2.           |
| ings, erc.         .9998         1.0         .9998         .0038         All failures         1.0         .9998         1.0           .9983         .9992         .9991         .023         All failures         .9992         .9991         1.0           .9983         .9985         .9985         -         -         No ignifion         .9995         -           .9988         1.0         .9988         1.0         .9988         1.0         .9988         1.0  | Hardwa   | 1866         | 6666      | . 9982               | .039      | Excessive leakage                        | 6666   | . 9982       | 0.1          |
| .9982         .9992         .9991         .023         All failures         .9992         .9991         1.3           .9982         .9983         -         -         No ignition         .9995         -           .9995         .9995         -         -         No ignition         .9995         -           .9988         1.0         .9988         .027         All failures         1.0         .9988         1.   | Firtings,  | 8666.        | 1.0       | 8666.                | . 0038    | All failures                             | 1.0  | 8666         | 0            |
| . 9982   | Engine Relay Box (10 relays)                       | .9983        | . 9992    | 1666                 | .023      | All failures                             | 2666   | i&&.         | 0            |
| . 9995 . 9995 — No ignition . 9995 — 9988  | T.C. & G.G. lanitors                               | . 9982       | .9982     | 1                    | 1         | No ignition                              | 9982   |              | -            |
| 9988 1.0 .9988 .027 All failures 1.0 .9988   | Hypergol lanitors                                  | 5666         | \$666.    | 1                    | 1         | No ignition                              | . 9995   | -            | 1            |
|  | Tuhe Pump  | 8866         | 0.1       | 8866                 | .027      | All failures                             | 1.0  | 8866         | 1.0          |

\*For naminal 160 second run time.



which is released from the launch pad after engine ignition and an initial hold-down phase; (2) an upper stage vehicle such as the S-II which is ignited in flight with no hold-down; and (3) the S-IVB stage which may be ignited and shut down more than once in a single mission.

The various vehicle operating modes that are possible can be considered to be different combinations of three operating phases: a starting phase, a running or operating phase, and a shutdown phase. For the purposes of the propulsion system reliability analysis, the operating modes of the Saturn V stages were assigned to these three phases as follows:

- 1. Start The phase of operation beginning with the initiation of the engine start cycle (including cool-down of the S-II and S-IVB stages) and extending until 3 seconds after full main engine thrust has been attained.
- 2. Run The principal operating phase, beginning with the end of the start phase and continuing until the initiation of the shutdown phase.
- 3. Shutdown The phase of operation beginning with the initiation of engine shutdown and proceeding until complete termination of thrust has been attained.

The apportionment of the component failure data into the three operating phases was based on data furnished by Rocktdyne<sup>1</sup> and indicates the distribution of cutoff failures between ignition plus 3 seconds of full thrust (start phase) and the full duration, full thrust operation (run phase) for the Atlas booster and sustainer. Thor, and H-1 engines. The apportionment of the data into failure modes or phases not described in the Rocketdyne data was made by considering either of the modes of failure in question as equally likely to happen (fail open is as likely as fail closed).

A main oxidizer valve can be used as an example. Since this valve failing open during the start phase would not be apparent until shutdown, this failure would not be recorded as a start phase failure. Thus all the failures indicated for the start phase must be due to the valve failing closed. The remaining, or run phase, portion of the valve failure probability was then equally apportioned between the other phases and modes included in the cutoff failure data (fail open during the start, run or shutdown phases, or fail closed during the run phase). The probability of failing closed during the shutdown





phase, which was not included in the cutoff data, was then considered to exhibit the same reliability as during the start and run phases. Other component reliability estimates were apportioned in a similar manner.

The component failure rate estimates listed in Table 2 were made by:

- 1. Assuming rocket engine components exhibit a constant failure rate with time after the starting transients are eliminated,
- 2. Weighting, or apportioning, of the failures between the various components by using the hot fire test stand data (e.g., determining a solenoid valve is X times more reliable than a turbopump), and
- 3. Assuming the ratio of inflight-failure-rate to test-stand-failure-rate of the engine system components is the same as that exhibited by the complete engine system.

An analysis of hot fire engine test stand data indicates that, during the steady state operation of the engine (run phase), the engine failure rate is constant with time. The failure rate is constant because:

- I. The components used on the engines for the hot fire stand tests are all debugged and checked out before use and the only hot fire engine tests considered were for engines in advanced stages of development.
- 2. The engines and/or engine components used in the hot fire tests are replaced before wearout becomes a factor.

Finally, it should be noted that in a past study<sup>3</sup> performed by TEMPO personnel, close correlation between actual missile flight subsystem failure data and the test stand component failure data was obtained by comparing the former with state-of-art estimates made for the same systems using the test stand component failure data in Table 2.





# SECTION III FAILURE ANALYSIS RESULTS

Figure 3 is a block diagram of the S-II or S-IVB propulsion system. The S-IC propulsion system is similar except that no "chill down" is required. Reliability estimates are made for the systems NEOC (no engine-out capability) and SEOC (single engine-out capability).

Distinction between safe shutdown and catastrophic failure of an engine has been made in these estimates. The safe shutdown (SSD) mode does not in itself imply "engine out" capability but does prevent engine destruction of the stage and the resulting immediate abort. The SSD mode actually allows an alternate mission capability and increased manned safety including a time delay for aborts.




Figure 3. Block diagram of J-2 propulsion system





Figures 4 through 11 in the pages which follow present simplified schematics of the following equipment systems which comprise the propulsion systems of the Saturn V vehicle:

- 1. F-1 engine of S-IC stage
- 2. S-IC stage fuel system
- 3. S-IC stage oxidizer system
- 4. S-IC stage control pressure system
- 5. J-2 engine
- 6. S-II stage hydraulic system
- 7. S-IVB stage hydraulic system
- 8. S-II and S-IVB stages tank and propellant feed system.

Tables 3 through 10 which follow the illustrations are "short form" failure analysis charts for the systems listed above. The short form is a simplified first estimate malfunction analysis in which redundant failure modes are not considered since the analysis covers only major considerations. Each system is considered for the various phases of operation: purge, chill down (when required), engine start, run, and shutdown (when a restart is required), or stop (when a restart is not required).

Figure 12 is a plot of the reliability of the cluster (number of successful stage operations before a failure) versus the single engine reliability for a cluster of five F-1 or five J-2 engines, four of which are gimballed. The graph is based on the concepts presented in the TEMPO report<sup>3</sup> on Saturn C-I "Engine-Out Study," performed for NASA. The five curves take into account the thrust vector control (TVC) system and the sensor system.

The TVC system reliability is based on the following equation:

$$P_v = 1 - 0.1 (1 - P_{e0})$$

where  $P_{e0}$  is the total engine reliability and  $P_v$  is the TVC system reliability in the catastrophic failure mode.








Figure 4. F-1 engine schematic S-IC stage single engine subsystem





#### Table 3.

FAILURE ANALYSIS CHART FOR:

S-IC STAGE OF SATURN V VEHICLE

SYSTEM: F-1 SINGLE ENGINE SUBSYSTEM

STATE-OF-THE-ART RELIABILITY ESTIMATE

O. ALL FAILURES

1. ALL ENGINES FAIL

2. SINGLE ENGINE FAILURE

4. CATASTROPHIC EXPLOSION

| COMPONENT                             |                | COMPONENT FAILURE MO   |                     | EFFECT OF COMPONENT | ULTIMATE<br>SYSTEM | ASS      | IGNAB! | ABILITY      |
|---------------------------------------|----------------|--|---------------------|---------------------|--------------------|----------|--------|--------------|
|                                       | _ £            |  | ក្តឡ                |                     | FAILURE<br>MODE    | EAC      | PHAS   |              |
|                                       | PIND<br>NUMBER |  | 28                  |                     | 1,11000            |          | (X     | 10 1         |
|                                       | ır D           |  | REFERENCE<br>NUMBER |                     |                    | START    | RUN    | SHUT<br>DOWN |
| Thrust Chamber                        | L              | Combustion instabil-<br>ity, injector failure,<br>burn through, etc. | 1                   |                     | 2,4                |          | 44     |              |
| Main Fuel Valve                       | 2              | Fail open  | 2                   |                     | 0                  |          | 0      |              |
| (Any of two)                          |                | Fail closed  | 3                   |                     | 2                  |          | 0      |              |
| Fuel Pilot Valve                      | 3              | Fail open  | 4                   |                     | 0                  |          | (2)1   | l            |
| (Any of two)                          |                | Fail closed  | 5                   |                     | 2                  |          | (2)1   |              |
| Igniter Fuel Valve                    | 4              | Fail open  | 6                   | Valves are redundan | 0                  |          | 0      |              |
| (Either of two)                       |                | Fail closed  | 7                   |                     | 0                  |          | (2)1   | ļ            |
| Sequence Valve                        | 5              | Fail open  | 8                   |                     | 0                  |          | 1      |              |
|                                       |                | Fail closed  | 9                   |                     | 2                  |          | 1      |              |
| Main Oxidizer Valve                   | 6              | Fail open  | 10                  |                     | 0                  |          | (2)2   | ļ            |
| (Either of two)                       |                | Fail closed  | 11                  |                     | 2                  |          | (2)2   | <u> </u>     |
| Oxidizer Pilot Valve                  | 7              | Fail open  | 12                  |                     | 0                  |          | (2)1   | ļ <u>.</u>   |
| (Either of two)                       |                | Fail closed  | 13                  |                     | 2                  |          | (2)1   | ļ <u>.</u>   |
| Gas Generator Valve                   | 8              | Fail open  | 14                  |                     | 0                  |          | Z      | _            |
|                                       |                | Fail closed  | 15                  |                     | 2                  |          | 2      |              |
| Four-way Solenoid                     | 9              | Fail open  | 16                  |                     | 0                  | <u> </u> | 1      | ļ            |
| Start Solenoid                        | _              | Fail closed  | 17                  |                     | 3                  | <u></u>  | 1      | ļ            |
| Four-way Solenoid                     | 10             | Fail open  | 18                  |                     | 2<br>              |          | 1      | <b>.</b>     |
| Cut-off Solenoid                      |                | Fail closed  | 19                  |                     | 3                  | <u> </u> | 1      |              |
| Gas Generator                         | 1              | Combustion instabil-<br>ity, injector failure,<br>burn through, etc. | 20                  |                     | 2                  |          | 4      |              |
| Exhaust Duct and<br>Manifold          | 12             | Rupture or burn<br>through   | 21                  |                     | Z                  |          | 2      |              |
| Tübes, fittings, Lines<br>and Gaskets |                | Rupture or excessive leakage   | 22                  |                     | 2                  |          | 18     |              |
| Turbopump Assembly                    | 13             | Mechanical failure   | 23                  |                     | 2                  |          | 14     |              |
| Check Valves                          | 4              | Fail open  | 24                  |                     | 2                  |          | (2)1   |              |
| (Either of two)                       |                | Fail closed  | 25                  |                     | 0                  | ļ        | 0      |              |
|                                       | 1              | T  |                     |                     | TOTAL              |          | 98     |              |





## Table 3. (Cont'd)

FAILURE ANALYSIS CHART FOR: S-IC STAGE OF SATURN V VEHICLE

SYSTEM: F-1 Engine (continued)

SYSTEM FAILURE MODES:

1. ALL ENGINES FAIL 3. GUIDANCE FAILURE
2. SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT                             |        | COMPONENT FAILURE MC   |                     | FAILURE MODE   | ULTIMATE<br>SYSTEM<br>FAILURE | ASS   | IG NAB | ABILITY<br>LE TO<br>ATING<br>E-4 |
|---------------------------------------|--------|--|---------------------|----------------|-------------------------------|-------|--------|----------------------------------|
|                                       | 2 gg   |  | ABEN C              |                | MODE                          |       | PHAS   | E-4                              |
|                                       | NUMBER |  | REFERENCE<br>NUMBER |                |                               | START | RUN    | SHUT                             |
| F-1 SINGLE ENGINE SU                  | вѕу \$ | TEM RUN RELIABILIT   | Υ =                 | . 9902         |                               |       |        |                                  |
|                                       |        |  |                     |                |                               |       |        |                                  |
| Gimbal Actuator<br>Lines and Fittings |        | INTEGRAL HY DRA  Rupture or excessive leakage                          | ١.                  |                | 3                             |       | 3      |                                  |
| Gimbal Actuator<br>and Servo          | 15     | All failures   | 27                  |                | 3                             |       | (2)5   |                                  |
| (Either of two)                       |        |  |                     |                |                               |       |        | <u> </u>                         |
| NOTE: The comp                        | onen   | LIC SUBSYSTEM REL<br>reliability estimates<br>allure data obtained fro | given<br>om cu      | here<br>irrent | TOTAL                         |       | 13     |                                  |
| LOX-RPI                               | prop   | ellant large rocket enĝ  | nes.                |                |                               |       |        |                                  |
|                                       |        |  |                     |                |                               |       | 1      | MP 3306                          |








Figure 5. S-IC stage fuel system




Figure 6. S-IC stage oxidizer system of Saturn V vehicle



#### Table 4.

FAILURE ANALYSIS CHARL (SHORL FORM) FOR: S-IC STAGE OF SATURN V VEHICLE

SYSTEM: FUEL SYSTEM

STATE-OF-THE-ART RELIABILITY ESTIMATE

SYSTEM FAILURE MODES:

0. NO FAILURE:
1. ALL ENGINES FAIL 3. GUIDANCE FAILURE
2. SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT                         |          | COMPONENT FALLER MO                     |                     | EFFECT : COMPONENT<br>FAILURE MODE | ULTIMATE<br>SYSTEM                               | FAILUI<br>ASS | RE PROB          | ABILITY<br>LE TO |
|-----------------------------------|----------|---|---------------------|------------------------------------|--|---------------|------------------|------------------|
|                                   | A CASES  |   | REFERENCE<br>NUMBER |                                    | FAILURE<br>MODE                                  | EACI          | H OPERA<br>PHASE |                  |
|                                   | er O     |   | NCE<br>NCE          |                                    |  | START         | RUN              | TUHE<br>NWOO     |
| Disconnect-helium fill.           | 101      | fails open.                             | 1                   |                                    | 0,1  |               | 1,0              | -                |
| Filter-helium fill,               | 102      | leakage.                                | г                   |                                    | 0  |               | 1.0              | ļ                |
| Shut-off valve helium             | 103      | Fails open.                             | 3                   |                                    | 1  | ↓             | . 9999           |                  |
| ill.                              |          | Fails closed.                           | 4                   |                                    | 0  | <del> </del>  | . 9999           | <b>!</b>         |
| lelium storage                    | 104      | Ruptures; ar outlet                     | 5                   |                                    | 1  | 1             | 1.0              | l                |
| oottles (4).                      |          | plugs.                                  |                     |                                    | <u> </u>   | <del> </del>  | . 9991           | i                |
| ligh pressure O.K.                | 105      | Fails to come on at                     | 6                   |                                    | l '  |               | 1                | 1                |
| witch-helium.                     |          | 3050 psig.                              | 7                   |                                    | 1  | <b> </b>      | . 9998           |                  |
|                                   |          | Fails to go off at                      | '                   |                                    | 1  | 1             |                  |                  |
|                                   | 106      | less than 2850 psig. Rupture or burnout | 8-                  |                                    | 1  | 1             | . 998            | 1                |
| Helium heat exchangers            | 100      | of interface, loss of                   |                     |                                    |  | İ             | 1                |                  |
| F-1 engines (5)<br>(any of five). |          | turbine exhaust flow                    |                     |                                    | Ħ  | 1             | 1                |                  |
| (any of five).                    | ]        | or loss at helium                       |                     |                                    |  |               | 1                | ļ                |
|                                   |          | flow.                                   |                     |                                    | <b></b>  | 1             | 1                | <u></u>          |
| Pressure relief                   | 107      | Fail open in flight.                    | 9                   |                                    | <u> </u>   | ļ:            | . 999            |                  |
| valve-He manifold.                |          | Fail closed in flight.                  | 10                  |                                    | 1 -1 -   | ·             | . 999            |                  |
| Flow control valves-              | 108      | Fail open.                              | 11                  |                                    | <del>                                     </del> |               | .999             |                  |
| Helium (5) (any of five).         |          | Fail closed.                            | 12                  |                                    | <u> </u>   |               | 1                | 1                |
| Container pressure                | 109      |   | 13                  | Redundant with vent                | 1  | 1             | . 999            | 14               |
| control switch.                   |          | overpressure or                         |                     | valve (110),                       |  | 1             | 1                |                  |
|                                   |          | indicates overpres-                     | 1                   |                                    | ·  | İ             | 1                | 1                |
|                                   | ŀ        | sure when none occurs.                  |                     |                                    |  | 1             | 1                |                  |
|                                   | 110      |   | 14                  |                                    | #  | -             | . 999            | 9                |
| Vent valve-fuel tank.             | 1110     | Fails closed.                           | 15                  | Redundant with (111),              | 4  |               | . 999            | 9                |
| Flight relief switch.             | 1111     | Fails to indicate                       | 16                  | Redundant with (110).              |  |               | . 999            | 9                |
| Flight Teller switch.             | 1        | overpressure.                           | 1                   |                                    | <b>1</b>   |               | 1                |                  |
|                                   |          | False indication of                     | 17                  |                                    | 1  |               | . 999            | 8                |
|                                   |          | overpressure.                           | <u> </u>            | <u> </u>                           | <b></b>  |               | +                | -                |
| Disconnect-ground He              | 112      | Excess leakage.                         | 18                  |                                    | 0  | ļ             | 1.0              |                  |
| pressurization.                   |          | 1                                       | <u>Ļ.</u> .         | #                                  | 1-0  |               | 999              | d                |
| Check valve-ground He             | 113      |   | 19                  | <b>#</b>                           | 0  |               | 999              |                  |
| pressurization.                   | 1        | Fails closed                            | 20                  | <b> </b>                           | 1,4  |               | 1.0              | 1                |
| Fuel tank,                        | 114      | Leakage; or rupture                     |                     |                                    | 4  |               |                  |                  |
| Fuel level-sensor                 | 115      | Indicates level                         | 22                  |                                    | 1  | į             | . 999            | '8               |
|                                   | L.,      | inaccurately.                           | <u> </u>            | <u> </u>                           |  | -+            | 1.0              |                  |
| Pneumatic valve-fuel              | 116      |   | 23                  |                                    | 0  | <del></del>   | 1.0              | +                |
| fill.                             | <u> </u> | Fail closed,                            | 24                  | #                                  | 0  |               | 1,0              | -                |
| Disconnect - Fuel fill            | 117      | Excess leakage.                         | 2.5                 | 1                                  |  |               |                  |                  |
| Pneumatic valves fuel             | 118      | Fail open.                              | 26                  | ·                                  | 2  |               | 1.0              | +                |
| feed (10).                        | 1        | Fail closed.                            | 27                  |                                    | 1 2  |               | 1.0              | 7                |
| Fuel Feed Lines                   | 119      | Excessive leakage                       | 28                  |                                    | 2,4  |               | 1. 775           | Ή                |
| 12" diameter (10).                | _1       | <u> </u>                                | 1                   | H                                  | 10   |               | . 999            | 7                |
| 141                               | 120      | - H                                     | 29                  |                                    | 1 -  |               | 996              |                  |
| Fuel fill lines (1).              | 121      | Excessive leakage.                      | 30                  | 1,                                 | 11 '   | - [           | [ ''             |                  |
| High Pressure-He                  | 1.0.     | 1                                       |                     |                                    |  |               |                  |                  |
| High Pressure-He<br>Tubing,       | 1        |   | <del>  ,,</del>     |                                    | 0  | _             | . 999            | 97               |
| High Pressure-He                  | 122      |   | 31                  |                                    | 0  |               | . 999            | 97               |





Table 5.

FAILURE ANALYSIS CHART (SHORT FORM) FOR: \_\_\_\_S-IC\_Stage of Saturn V Vehicle\_\_\_\_\_

SYSTEM: Oxidizer System

State of the Art Reliability


Estimate


SYSTEM FAILURE MODES:

1. ALL ENGINES FAIL 3. GUIDANCE FAILURE
2. SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT                                    |        | COMPONENT FAILURE MO   |                     | EFFECT OF COMPONENT<br>FAILURE MODE                            | SYSTEM          | ASS   | IGNAB          | LE TO |
|--|--------|--|---------------------|--|-----------------|-------|----------------|-------|
|  | Z T    |  | REFERENCE<br>NUMBER |  | FAILURE<br>MODE | EACH  | OPER/<br>PHASE |       |
|  | NUMBER |  | ABER<br>ENCE        |  |                 | START | RUN            | SHUT  |
| LOX tank                                     | 150    | Excess leakage or rupture  | 1                   |  | 2, 4            |       | 1.0            |       |
| LOX fill valve - pneumatic (either of two)   | 151    | Fails open<br>Fails closed   | 3                   |  | 1 0             |       | 9996           | 1     |
| LOX fill lines & fittings<br>(either of two) | 152    | Excess leakage or rupture  | 4                   |  | 0               |       | 9994           |       |
| LOX feed valves (any of five)                | 153    | Fail open<br>Fail closed   | 5                   |  | 0<br>1          |       | 9990           | 1     |
| LOX feed lines & fittings (any of five)      | 154    | Excess leakage or rupture  | 7                   |  | ]               |       | 9985           |       |
| LOX level sensor                             | 155    | Inaccurate level indication  | 8                   |  | 1, 2            |       | 9998           |       |
| Pressure relief switch<br>LOX tank           | 156    | Fails on; when should<br>be off<br>Fails off; when should<br>be on | 1                   | Redundant with vent<br>valves<br>Redundant with vent<br>valves | 4               |       | 9998           | 1     |
| Vent - Relief                                | 157    | Fails open   | 11                  | Redundant with pressure switch                                 | 1               |       | 9999           |       |
| Valve LOX tank<br>(either of two)            |        | Fails closed   | 12                  | pressure awiten  | 4               |       | 9999           |       |
| LOX check valve (any of five)                | 158    | Fails open<br>Fails closed   | 13                  |  | 1<br>0          |       | 9995           | i     |
| GOX lines and fittings                       | 159    | Excess leakage or rupture  | 15                  |  | 1               |       | 9997           | '     |
| Heat exchangers (any of five)                | 160    | Burn through or loss<br>of GOX or turbine gas<br>glow              | 16                  |  | 1               |       | 9985           | 5     |
| GOX flow control valve                       | 161    | Fail open<br>Fail closed   | 17<br>18            |  | 1               |       | 9999           |       |
| Pressure sensor-GOX flow control             | 162    | Inaccurate indication of LOX tank pressure                         | 19                  |  | 1, 4            |       | 999            | 8     |
| He - ground pressuriza<br>tion disconnect    | 16:    | Fail open<br>Fail closed   | 20<br>21            |  | 1<br>0          |       | 1.0            |       |
| He - ground pressuri-<br>zation lines        | 164    | Excess leakage or rupture  |                     |  | 0               |       | 999            | 7     |
| £  |        | SYSTEM RE  | LAB                 | II. ITY = . 9931   |                 |       |                |       |










Figure 7. J-2 Engine system schematic



Table 6.

FAILURE ANALYSIS CHART FOR: J-2 ENGINE SYSTEM

SYSTEM: a) Engine Oxidizer Subsystem

| COMPONENT  | <del>T</del> - | COMPONENT FAILURE M  |           | EFFECT OF COMPONENT FAILURE MODE                          | PRE START |       | RE PRO         |      |      | 1 |
|--|----------------|--|-----------|---|-----------|-------|----------------|------|------|---|
|  | PIND           |  | REFERENCE |   | DOWN)     | EAC   | H OPER<br>PHA! | ATIN | ۹G   |   |
|  | " Z            |  |           |   |           | START | RUN            | Si   | HUT  | 1 |
| a) Engine Oxidizer<br>Subsystem:   |                |  |           |   |           |       |                | 5-11 | S-IV |   |
| Emergency shut off<br>oxidizer valve and pres-<br>sure relief vent               | 21             | Fails to remain open, or closes premature-<br>ly.  |           | Engine operation terminated (SSD).                        | 0         | 4     | 2              | 0    | 2    |   |
| (SL. ;G, Sg. , N. O. )<br>(see code)   |                | Pressure relief vent<br>fails.<br>Fails open, when<br>commanded to close.                                  |           | Probable engine destruction.                              | 0         | (2)   | (2)            | 0    | (2)  |   |
| LO <sub>2</sub> Turbopump  | 22             | During GH <sub>2</sub> startup,<br>and expiration of<br>mainstage timer;<br>during mainstage<br>operation— |           | Engine operation<br>terminated (SSD)                      | 0         | 1     | 14             | 0    | 0    |   |
|  |                | Contamination  |           | Fires, explosions.  | 0         | 0     | (2)            | 0    | 0    | ĺ |
| LO <sub>2</sub> Flowmeter  | 23             | Bearing function, or contamination   |           | Fires, explosions.  | 0         | 0     | (1)            | 0    | 0    |   |
| O <sub>2</sub> turbopump seal cavity purge bleed check valve.                    | 24             | Leaks, or fails to close, fails to open.   |           | Contamination,<br>ox pump freeze-up—<br>possible damage,  | 1         | 0     | 1              | 0    | 0    |   |
| (SL, P, Hy, N.C.)  |                |  |           | fire hazard.  | (1)       | 0     | (1)            | 0    | ٥    |   |
| LO <sub>2</sub> Propellant Utiliza-<br>tion Valve                                | 25             | Fails to operate (normal position).  |           | Probability of inef-<br>ficient use of propel-<br>lants.  | 0         | 0     | 1              | 0    | 0    |   |
|  |                | Fails to operate<br>(extreme position).  |           | n ti ii   | 0         | 0     | 1              | 0    | 0    |   |
| (V. F., SM, NO,)   |                | PU valve not in nor-<br>mal position during<br>start or shut down.   |           | Engine start not<br>achieved. Pump<br>stalls.             | 1         | 1     | 0              | 0    | 1    |   |
| Main LO <sub>2</sub> (MOV) valve   | 26             | Fails to open, (FC).   |           | Engine cut off (SSD)                                      | 0         | 4     | 2              | 0    | 2    |   |
| (SL., G, two-stage operation, Pn, N. C.,)  |                | Fails to close, (FO).  |           | Possible stage sep-<br>aration problems.                  | 0         | 0     | 0              | 1    | 2    |   |
| Sequencer valve of main<br>LO <sub>2</sub> valve (pneumatic)                     | 27             | Fails to open, (FC).   |           | Engine cut off (SSD).                                     | 0         | 5     | 0              | 0    | 0    |   |
| (3 way-Pn-mech-linked<br>to MOV)   |                | Fails to close, (FO).  |           | May result in Ox rich cut off T/C damage and Ox drainage. | 0         | 0     | 1              | 0    | 1    |   |
| Pressure Actuator con-<br>rol valve of main LO <sub>2</sub><br>valve (3 way-Pn-) | 28             | Fails to open.   |           | Engine C/O by main-<br>stage timer (SSD).                 | 0         | 5     | 0              | 7    | 0    |   |
| valve to way-rn-)  |                | Premature opening or locked in open position cannot close at C/O.  |           | Fuel pump stall, over temp. due to LOX rich condition.    | 0         | 2     | 2              | )    | 2    |   |



page 2



## Table 6. (Cont'd)

FAILURE ANALYSIS CHART FOR: J-2 ENGINE SYSTEM (continued).

SYSTEM: b) Engine Fuel Subsy. ... m.

| COMPONENT  |                | COMPONENT FAILURE MC   | DDE                 | EFFECT OF COMPONENT  | CHILL |       | RE PROI |             |            |   |
|--|----------------|--|---------------------|--|-------|-------|---------|-------------|------------|---|
|  | FIND<br>NUMBER |  | REFERENCE<br>NUMBER | FAILURE MODE   | DOWN  |       | PHAS    | <b>ATIN</b> |            |   |
|  | ır Z           |  | REFE                |  |       | START | RUN     |             | TUT<br>NWC |   |
|  |                |  |                     |  |       |       |         | S-11        | SIV        | P |
| ASI-Augmented spark igniter oxidizer valves.                       | 29             | Fails to open.   |                     | May result in hard start or detonation.  | 0     | 1     | (1)     | 0           | 1          |   |
| (P, Pn, NC)  |                | Fails to close.  |                     |  |       |       |         |             |            |   |
| Oxidizer turbine bi-pass<br>valve.                                 | 30             | Fails closed, fails to open after cut off.   |                     | No restart (uel pump stall.  | 0     | ì     | 1       | 0           | 1          |   |
| (SL; G, N.O.)  |                | Fails open (fails to<br>close during start)  | -                   | Excessive GG by-<br>pass - low perf.   | 0     | 2     | 0       | 0           | 1          |   |
| b) Engine Fuel<br>Subsystem:                                       |                |  |                     |  |       |       |         |             |            |   |
| Emergency shut-off<br>fuel valve                                   | 31             | Fails to remain open, or closes prematurely  |                     | Engine operation terminated (SSD).   | 0     | 4     | 2       | 0           | 2          |   |
| (S. L; G, Sq, N. O.)   |                | Fails open, when commanded to close.   |                     | Engine destruction   | 0     | (2)   | (2)     | 0           | (2)        |   |
| LH <sub>2</sub> Turbo pump   | 32             | Failure during GH <sub>2</sub> startup, and expiration of mainstage timer; during mainstage stage operation. |                     | Engine operation<br>terminated (SSD),  | 0     | 1     | 14      | 0           | 0          |   |
| LH <sub>2</sub> Flow meter   | 33             | Fails  |                     | Probable, will not affect operation.   | 0     | 0     | 0       | 0           | 0          |   |
| H <sub>2</sub> turbo pump seal<br>cavity purge and bleed           | 34             | Leaks or fails to close.   |                     | Pump freeze-up<br>failure.   | Z     | 0     | г       | 0           | 0          |   |
| system. 3 req'd.   |                | Fails to open.   |                     | Fire hazard  | (2)   | 0     | (2)     | 0           | 0          |   |
| Main fuel valve (MFV)  | 35             | Fails to open fully.   |                     | No engine start (SSD)  | 0     | 2     | 0       | 0           | 1          |   |
| (Two position; G, Pn)  |                | Fails to close (FO).   |                     | No effect, except for re-start.  | 0     | 0     | 0       | 0           | 1          |   |
| Thrust chamber fuel jacket purge and pre-<br>conditioning connect. | 36             | Fails closed,  |                     | Prevents purge opera<br>tion, may cause hard<br>start due to improper<br>chill down. | . 1   | 0     | 0       | 0           | 0          |   |
|  |                | Fails open.  |                     | Prevents past firing purge.  | 0     | 0     | 0       | 0           | 1          |   |
|  |                |  |                     |  |       |       |         |             |            |   |



#### Table 6. (Cont'd)

page 3

FAILURE ANALYSIS CHART FOR: J-2 ENGINE SYSTEM (continued).

- SYSTEM: c) Engine Gas Generator Subsystem.
  - d) Engine Pneumatic Control Package Subsystem.

| COMPONENT   |        | COMPONENT FAILURE MC             |           | EFFECT OF COMPONENT FAILURE MODE  | CHILL  |        | IGNAB           | LE TO     | 2         |
|---|--------|----------------------------------|-----------|---|--------|--------|-----------------|-----------|-----------|
|   | NUMBER |                                  | REPERENCE |   | DOWIN  | EAC    | I OPER.<br>PHAS | ATIN<br>E | IG        |
|   | NUN.   |                                  | REFER     |   |        | START  | RUN             |           | IUT<br>WN |
|   |        |                                  |           |   |        |        |                 | S-11      | S-I       |
| C) Engine Gas Generato Subsystem:  G. G (H <sub>2</sub> ) bleed valve | 37     | Fails to open.                   |           | Engine cut off (SSD).   | 0      | 1      | l               | n         | 1         |
| mechanically linked. (P, Pn, N.C.).                                   |        | Fails to close.                  |           | G. G. burnout fire  | 0      | 5      | 1               | 1         | 1         |
| G. G. Solenoid control  | 38     | Fails open.                      |           | Engine will not bootstrap (SSD).  | 0      | 1      | 1               | n         | 1         |
| (3 position, P, Sd, N. C.)  |        | Fails closed                     |           | Engine cannot start.  | 0      | 1      | 1               | 0         | ı         |
| G.G. Injector assembly  | 39     | All failures.                    |           | SSD Detonations, fires.   | 0<br>0 | 7 (1)  | 3<br>(1)        | 0         | 0         |
| Heat exchanger assem-<br>bly.   | 40     | All failures,                    |           |   | 0      | 0      | 3               | 0         | 0         |
| Heat exchanger anti-<br>flood check valve (Ox.)                       | 41     | Fails.                           |           |   | 0      | 0      | ı               | 0         | C         |
| d) Engine Pneumatic<br>Control Package<br>Subsystem:                  |        |                                  |           |   |        |        |                 |           |           |
| Control Valve<br>4-way, P, Sol, bias to<br>keep MFV, MOV, GGV,        | 42a    | Fails to actuate when energized. |           | No engine start.  | 0      | 1      | 1               | 1         | ]         |
| closed.<br>1) Ignition Phase  |        | Fails to close when deenergized. |           | Fuel rich cut off.  | 0      | 0      | 0               | 0         | ]         |
| <ol> <li>Main stage operation phase.</li> </ol>                       | 42b    | Fails to actuate when energized. |           | No engine start at expiration of main stage timer.                      | 0      | 1      | 1               | 1         | 1         |
| •   |        | Fails to close when deenergized. |           | MOV & GGV will not close, O <sub>2</sub> rich cut off GG & TC burn out. | 0      | 0      | 0               | 1         | ]         |
| G.G. bleed valve contro<br>Solenoid valve                             | 43     | Fails open.                      |           | See gas gen. sub-<br>system. (37)                                       | 0      | 1      | 1               | 0         | ,         |
| Helium control  | 14     | Fails open.                      |           | No restart capability.  | 0      | 1<br>1 | 0               | 0         | 1         |
|   |        | Fails closed.                    | -         | (SSD)   | 0      | 2      | 0               | 0         |           |
| Two-vent port check valves  | 45     | Fails open.                      |           | No He pressure for engine start.  No restart.                           | U      | 2      |                 | ľ         | '         |



### Table 6. (Cont'd)

page 4

FAILURE ANALYSIS CHART FOR: J-2 ENGINE SYSTEM (continued)

SYSTEM: e) GH, Start and Tank Pressurization

f) Miscellaneous Engine Subsystems.

| COMPONENT   |                | COMPONENT FAILURE MODE   |  | EFFECT OF COMPONENT         | CHILL | FAILURE PROBABILITY ASSIGNABLE TO |   |      |      | ŀ |
|---|----------------|--------------------------|--|-----------------------------|-------|-----------------------------------|---|------|------|---|
|   | FIND<br>NUMBER |                          | No engine start.                         | OPER<br>PHAS                | ATIN  |                                   |   |      |      |   |
|   | πò             |                          |  |                             | START | RUN                               |   | TUI  |      |   |
|   |                |                          |  |                             |       |                                   |   | S-11 | S-IV | 1 |
| Vent port relief valve (high pressure).                                     | 46             | Fails open.              |  | No engine start.            | 0     | 1                                 | 0 | 0    | 1    |   |
| Low pressure relief valve.  | 47             | Fails open.              | ر در | No engine start.            | 0     | 1                                 | 0 | 0    | 1    |   |
| Roughing regulator.   | 48             | Fails high.              |  |                             |       | 0                                 | 0 | 0    | 0    |   |
|   |                | Fails low.               |  | Performance loss.           | 0     | 1                                 | 2 | 0    | 0    |   |
| 4 He check valves.  | 49             | Fails open.              |  |                             | 0     | 0                                 | 4 | 0    | 0    |   |
| e) GH <sub>Z</sub> Start and LH <sub>Z</sub> Tank Pressurization Subsystem: |                |                          |  |                             |       |                                   |   |      |      |   |
| Chamber gas filter.   | 50             | Fails.                   |  | Contamination.              | 0     | 0                                 | 1 | 0    | 0    |   |
| Check valves (two).   | 51             | Fails.                   |  | Loss of start.              | 0     | 1                                 | 0 | 0    | 1    |   |
| Pressure switch.  | 52             | Fails when required.     |  | Prevents restart.           | 0     | 0                                 | 0 | 0    | 2    |   |
|   |                | Open when not required.  |  | Redundant.                  |       |                                   |   |      |      |   |
| Start Tank Vent and<br>Relief Valve.  | 53             | Fails closed.            |  | of GH2 start tank,          | 0     | 0                                 | 1 | 0    | 0    |   |
|   |                | Fails open.              |  | Loss of restart.            | 0     | 0                                 | 0 | 0    | 1    |   |
| Start Tank discharge<br>valve (SL, G, Pn, N.C.)                             | 54             | Fails to open for start. |  | 81                          |       | 5                                 | 0 | 0    | 0    |   |
|   |                | Fails open after start   |  | ducts on discharge          | 0     | 0                                 | 0 | 0    | 1    |   |
| Start Tank discharge  | 55             | Fails to open.           |  | Prevents start cycle.       | 0     | 1                                 | 0 | 0    | 1    | ĺ |
| solenoid control valve.   |                | Fails to close.          |  | Prevents restart.           | 0     | 1                                 | 0 | 0    | 1    |   |
| f) Misc. Engine Subsystems:   |                |                          |  |                             |       |                                   |   |      |      |   |
| Main stage O. K.<br>pressure switch   | 56             | Fails when required.     |  | No mainstage signal (SSD).  | 0     | 4                                 | 0 | 0    | 0    |   |
|   |                | Fails when not req'd.    |  | Shuts down engine in error. | 0     | 0                                 | 2 | 0    | 2    |   |
|   |                |                          |  |                             |       |                                   |   |      |      |   |
|   |                |                          | 1  | IL                          | I     | L                                 | L | L    |      | ł |





## Table 6. (Cont'd)

FAILURE ANALYSIS CHART FOR: J. 2 ENGINE SYSTEM (continued).

SYSTEM: f) Miscellaneous Engine Subsystems

page 5

| COMPONENT                                   |                | COMPONENT FAILURE MODE |                     | EFFFCT OF COMPONENT   | CHILL           | FAILURE PROBABILITY ASSIGNABLE TO |        |        |        |
|---|----------------|------------------------|---------------------|---|-----------------|-----------------------------------|--------|--------|--------|
|   | FIND<br>NUMBER |                        | REFERENCE<br>NUMBER | TATEONE MODE  |                 | EACH OPER<br>PHAS                 |        | RATING |        |
|   | E S            |                        | AEFER<br>NUN        |   |                 | START                             | RUN    | SHUT   |        |
|   |                |                        |                     |   |                 |                                   |        | S-11   | 5-IV 1 |
| Tubes, ducts, fittings.                     | 57             | All failures.          |                     | Some redundant patri<br>minor leaks.  | . 1             | 1                                 | 4      | 0      |        |
|   |                |                        |                     | Fires, explosions.  | 0               | 0                                 | (2)    | 0      | 0      |
| Elec. Cables, fittings.                     | 58             | Failures               |                     | (SSD)   | 0               | 0                                 | 2      | 0      | 0      |
| Thrust Chamber                              | 59             | Burn thru              |                     | (SSD)   | Z               | 2                                 | 13     | 0      | 0      |
|   |                | Combustion instability |                     | Fires, explosions.  | (1)             | 5                                 | (12)   | 0      |        |
|   |                |                        |                     | Σq  | (4)/8           | (5)/79                            | (27)/8 | (O)/7  | (4)/4  |
|   |                |                        |                     | Single J-2 Engine p <sub>eo</sub>   | = . <u>9782</u> |                                   |        |        |        |
|   |                |                        |                     | Single J-2 TVC PT   | = . <u>9970</u> |                                   | İ      |        |        |
|   |                |                        |                     | 5-II Stage, Engines a   | d TVC           |                                   |        |        |        |
|   |                |                        |                     | $\overline{P}_{5,4} \begin{pmatrix} 0 \\ 0 \end{pmatrix} = .890 \text{ (N.)}$   | t. O. C.)       |                                   |        |        |        |
|   |                |                        |                     | $\frac{\overline{P}_{5,4} \begin{pmatrix} 0 \\ 1 \end{pmatrix} = .890 \text{ (N.}}{\overline{P}_{5,4} \begin{pmatrix} 1 \\ 1 \end{pmatrix} = .972 \text{ (S. I)}}$ for $\overline{I}_E = $ Sensor Reliability | s, O. C.)       |                                   |        |        |        |
|   |                |                        |                     | for I <sub>m</sub> =  | 85%             |                                   |        |        |        |
|   |                |                        |                     | Sensor Reliability  | S = I -         | 1.25 (                            | - Pe   | ال     |        |
| where:                                      | , .            |                        |                     |   |                 |                                   |        |        |        |
| ( ) indicates catastro<br>SSD Safe Engine S |                |                        |                     |   |                 |                                   |        |        |        |
| F.O. Fails Open ;<br>c/o Cut Off            |                |                        |                     |   |                 |                                   |        |        |        |
| T/C Thrust Chamb                            | er             |                        |                     |   |                 |                                   |        |        |        |
| Valve Code:                                 |                |                        |                     |   |                 |                                   |        |        |        |
| SL Spring Loaded                            |                |                        |                     |   |                 |                                   |        |        |        |
| P Poppet<br>G <u>Gate</u>                   |                |                        |                     |   |                 |                                   |        |        |        |
| VF Variable Flow<br>Sol. Solenoid           |                |                        |                     |   |                 |                                   |        |        |        |
| Sq. Squibb Actuate                          |                |                        |                     |   |                 |                                   |        | l      | ı      |
| Pn Pneumatic Ope<br>Hy. Hydraulic Ope       | rated          |                        |                     |   |                 | }                                 |        |        |        |
| SM Servo Motor C<br>NO Normally Oper        |                | ⊵d                     |                     |   |                 |                                   |        |        |        |
| NC Normally Clos                            | eđ             |                        |                     |   |                 |                                   |        |        |        |
|   |                |                        |                     |   |                 |                                   |        |        |        |
|   |                |                        |                     |   |                 |                                   |        |        |        |
|   |                |                        |                     |   |                 |                                   |        |        |        |
|   |                |                        |                     |   |                 | _                                 |        |        |        |








Figure 8. S-IC stage control pressure system of Saturn V vehicle

#### Table 7.

FAILURE ANALYSIS CHART (SHORT FORM) FOR: S-IC Stage of Saturn V Vehicle

SYSTEM: Control Pressure System

State of the Art Reliability Estimate

n, No Failure MODES:

ALL ENGINES FAIL
 3. GUIDANCE FAILURE
 SINGLE ENGINE FAILURE
 4. CATASTROPHIC EXPLOSION

| COMPONENT  |       | COMPONENT FAILURE MO            | DDE          | EFFECT OF COMPONENT | ULTIMATE<br>SYSTEM<br>FAILURE<br>MODE | FAILURE PROBABILITY ASSIGNABLE TO EACH OPERATING PHASE |                  |               |
|--|-------|---------------------------------|--------------|---------------------|---------------------------------------|--|------------------|---------------|
|  | Z F   | 7                               | REFERENCE    | FAILURE MODE        |                                       |  |                  |               |
|  | NOWER |                                 | ABER<br>ENCE |                     |                                       | START  | RUN              | SHUT<br>NWO'r |
| GN <sub>2</sub> pressure tank No.<br>1               | 170   | Rupture or excessive leakage    | 1            |                     | 1                                     |  | 1.0              |               |
| GN <sub>2</sub> pressure tank<br>No. 2               | 171   | Rupture or excessive<br>Leakage | 2            |                     | 1                                     |  | 1.0              |               |
| Check valve - fill and<br>N, ground supply           | 172   | Fail open<br>Fail closed        | 3 4          |                     | 1<br>0                                |  | . 9993<br>. 9993 |               |
| GN, disconnect - fill and ground supply              | 173   | Fail open<br>Fail closed        | 5            |                     | . i                                   |  | 1.0              |               |
| Manifold relief valve                                | 174   | <br> Fail open<br> Fail closed  | 7<br>8       |                     | I<br>4                                |  | . 9999<br>. 9999 |               |
| Manifold lines and<br>fittings                       | 175   | Rupture or excessive<br>leakage | 9            |                     | 1                                     |  | . 9997           |               |
| Engine purge valve                                   | 176   | Fail open<br>Fail closed        | 10<br>11     |                     | 1<br>0                                |  | 1.0              |               |
| Engine purge lines and fittings                      | 177   | Rupture of excessive leakage    | 12           |                     | 1                                     |  | . 9998           |               |
| Fuel vent control valve                              | 178   | Fails open<br>Fails closed      | 13<br>14     | Redundant           | 1<br>4                                |  | . 9999<br>. 9999 |               |
| LOX vent control valve                               | 179   | Fails open<br>Fails closed      | 15<br>16     | Redundant           | 1<br>4                                |  | . 9999<br>. 9999 |               |
| Lines and fittings - vent                            | 180   | Rupture or excessive leakage    | 17           |                     | 0                                     |  | . 9997           |               |
| Fuel fill control valve                              | 181   | Fails open<br>Fails closed      | 18<br>19     |                     | <b>Z</b>                              |  | . 9999<br>. 9999 |               |
| Fuel fill lines and fittings                         | 182   | Rupture or excessive leakage    | 20           |                     | n                                     |  | . 9997           |               |
| LOX fill control valves                              | 183   | Fails open<br>Fails closed      | 21<br>22     |                     | 0<br>1                                |  | . 9999<br>. 9999 |               |
| LOX fill control lines and fittings                  | 184   | Rupture or excessive leakage    | 23           |                     | o                                     |  | . 9997           |               |
| Fuel and LOX feed<br>control valves (any of<br>five) | 185   | Fails open<br>Fails closed      | 24<br>25     |                     | 1<br>3                                |  | . 9999<br>. 9999 |               |
| Fuel and LOX control lines and fittings              | 186   | Rupture or excessive<br>leakage | 26           |                     | 1                                     |  | . 9997           |               |
|  |       |                                 |              |                     |                                       |  |                  |               |
|  |       | SYSTEM REL                      | JARII        | HTY = . 9981        |                                       |  |                  |               |
|  |       | O O I DI M REAL                 |              |                     |                                       |  |                  |               |




Figure 9. S-II stage hydraulic system



Table 8.

FAILURE ANALYSIS CHART (SHORT FORM) FOR: S-II STACE OF SATURN V VEHICLE

SYSTEM: Hydraulic

SYSTEM FAILURE MODES:

Single Engine Control Subsystem

STATE-OF-THE-ART RELIABILITY ESTIMATE

0, NO FAILURE
1. ALL ENGINES FAIL 3. GUIDANCE FAILURE
2. SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT  |                | COMPONENT FAILURE MODE                                   |                     | EFFECT OF COMPONENT FAILURE MODE | ULTIMATE<br>SYSTEM | FAILURE PROBABILITY ASSIGNABLE TO |                 |              |
|--|----------------|--|---------------------|----------------------------------|--------------------|-----------------------------------|-----------------|--------------|
|  | FIND<br>NUMBER |  | REFERENCE<br>NUMBER |                                  | FAILURE<br>MODE    |                                   | ATING<br>(X 10° |              |
|  | # D            |  | BER                 |                                  |                    | START                             | RUN             | SHUT<br>DOWN |
| Main Pump  | 70             | Mechanical Failure.                                      | 1                   |                                  | 3                  |                                   | 12              |              |
| Main Pump High Pressure Check Valve.                         | 71             | Fails open.  | 2                   |                                  | 3                  |                                   | 1               |              |
| Main Pump Case Drain<br>Check Valve,                         | 72             | Fails open. Fails closed.                                | 4                   |                                  | 0                  |                                   | 1               |              |
| Auxiliary Pump and   | 73             | Mechanical failure.                                      | 6                   |                                  | 0                  |                                   | 12              |              |
| Motor,  Auxiliary Pump High Pressure Check Valve.            | 74             | Fails open.  | 7 8                 |                                  | 0                  |                                   | 1               |              |
| Auxiliary Pump Case<br>Drain Check Valve.                    | 75             | Fails open. Fails closed.                                | 9                   |                                  | 0                  |                                   | 1               |              |
| Accumulator-<br>Reservoir Assembly,                          | 76             | Rupture or Leak<br>Excessively.                          | 11                  |                                  | 3                  |                                   | 2               |              |
| Filters in High Pressure Lines (Either of two).              | 77             | Element plugs. Element ruptures.                         | 12                  |                                  | 0                  |                                   | 0               |              |
| Relief Valves in High<br>Pressure Lines                      | 78             | Fails open.  | 14<br>15            | ***                              | 3                  |                                   | (2)1            |              |
| (Either of two).  Servo Actuator Assemblies (Either of two). | 79             | Mechanical failure,<br>rupture or leak ex-<br>cessively. | 16                  |                                  | 3                  |                                   | [2]1<br>[2]2    |              |
| High Pressure Lines and Fittings.                            |                | Rupture or leak excessively.                             | 17                  |                                  | 3                  |                                   | 3               |              |
| Low Pressure Lines and Fittings.                             |                | Rupture or leak excessively.                             | 18                  |                                  | 3                  |                                   | 2               |              |
| Ground Pressure Line Disconnect Assembly.                    | 80             | Fails open. Fails closed.                                | 19                  |                                  | 3                  |                                   | 0               |              |
| Ground Return Line Disconnect Assembly.                      | 8 I            | Fails open.  | 21                  |                                  | 3                  |                                   | 0               |              |
| SINGLE ENGINE HYD  | RAUI           | Fails closed.  |                     | = .9970                          | тот                | AL                                | 30              |              |




Figure 10. S-IVB stage hydraulic system



Table 9.

#### FAILURE ANALYSIS CHART (SHORT FORM) FOR: S-IVB STAGE OF SATURN V VEHICLE

SYSTEM: Hydraulic

SYSTEM FAILURE MODES:

Single Engine Control Subsystem
State-of-the-Art Reliability Estimate

0. NO FAILURE
1. ALL ENGINES FAIL 3. GUIDANCE FAILURE
2. SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT   |        | COMPONENT FAILURE ME                   |           | EFFECT OF COMPONENT  | ULTIMATE<br>SYSTEM |       | RE PROI      | BABILITY                     |
|---|--------|--|-----------|--|--------------------|-------|--------------|------------------------------|
|   | NUMBER |  | REFERENCE | TAILOILE MODE  | FAILURE<br>MODE    | ı     | OPER         | ATING<br>(X 10 <sup>-1</sup> |
|   | 77     |  | äë        |  |                    | START | RUN          | SHUT                         |
| Engine Driven Main<br>Pump  | 200    | Mechanical failure.                    | 1         |  | 3                  |       | 12           |                              |
| Main Pump High Pressure Line Check Valve  | 201    |  | 2         |  | 3                  |       | 1            |                              |
| Sare Bille Office Valve   |        | Fails closed.                          | 3         |  | 3                  |       | 1            |                              |
| Main Pump Case Drain<br>Line Check Valve  | 202    | Fails open.                            | 4         |  | 3                  |       | 1            |                              |
|   |        | Fails closed.                          | 5         |  | 3                  |       | 1            |                              |
| High Pressure Filter  | 203    | Element plugs. Element ruptures.       | 6         |  | 3                  |       | 0            |                              |
| Accumulator-<br>Reservoir Assembly  | 204    | Ruptures or leaks excessively,         | 8         |  | 3                  | 7     | 2            | ad Art des                   |
| High Pressure Relief<br>Valve   | 205    | Fails open.<br>Fails closed.           | 9<br>10   |  | 3                  |       | 1            |                              |
| Actuator Assembly<br>Prefiltration Valve<br>(Either of two)                       | 206    | Fails open,<br>Fails closed            | 11        |  | 0<br>3             |       | 1<br>1       |                              |
| Actuator Assembly   | 207    | Element plugs,                         | 13        |  | 3                  |       | (2)1         |                              |
| Filter<br>(Either of two)   |        | Element Ruptures.                      | 14        |  | 0                  |       | 0            |                              |
| Actuator Assembly<br>Bleed & Sample Valve<br>(Either of two)                      | 208    | Fails open.<br>Fails closed.           | 15<br>16  |  | 3                  |       | (2)1<br>(2)1 |                              |
| Actuator Assembly<br>Servo Valve (Either of<br>two)                               | 209    | Electrical or<br>mechanical failure.   | 17        | The state of the s | 3                  |       | (2)5         |                              |
| Actuator Piston, Engine<br>Linkage, and Feedback<br>Transducer (Either of<br>two) | 210    | Mechanical or<br>electrical failure.   | 18        |  | 3                  |       | (2)2         |                              |
| High Pressure Lines<br>and Fittings   |        | Rupture or leak excessively.           | 19        |  | 3                  |       | 3            |                              |
| Low Pressure Lines<br>and Fittings  |        | Rupture or leak excessively,           | 20        |  | 3                  |       | 2            |                              |
| Electric Motor Driven<br>Aux, Pump & Motor  | 211    | Electrical or mech-<br>anical failure. | 21        |  | 3                  |       | 12           |                              |
| Auxiliary Pump High   | 212    | Fails open.                            | 22        |  | 0                  |       | 1            |                              |
| Pressure Line Check<br>Valve  |        | Fails closed.                          | 23        |  | 3                  |       | 1            |                              |
| Auxiliary Pump Low  | 213    | Fails open.                            | 24        |  | 3                  |       | l            |                              |
| Pressure Line Check<br>Valve  |        | Fails closed.                          | 25        |  | 0                  |       | 1            | _                            |



#### Table 9. (Cont'd)

FAILURE ANALYSIS CHART (SHORT FORM) FOR: S-IVB STAGE OF SATURN V VEHICLE

SYSTEM FAILURE MODES:


SYSTEM: Hydraulic

Single Engine Control Subsystem

State of the Art Reliability Estimate

NO FAILURES
 ALL ENGINES FAIL 3. GUIDANCE FAILURE
 SINGLE ENGINE FAILURE 4. CATASTROPHIC EXPLOSION

| COMPONENT   |        | COMPONENT FAILURE MO            |                     | EFFECT OF COMPONENT FAILURE MODE              | SYSTEM          | ASS   | <b>IGNAB</b>     | LE TO  |
|---|--------|---------------------------------|---------------------|---|-----------------|-------|------------------|--------|
|   | NUMBER |                                 | REFERENCE<br>NUMBER |   | FAILURE<br>MODE | EACI  | H OPER-<br>PHASI | (X 10- |
|   | BET D  |                                 | PER CE              |   |                 | START | RUN              | SHUT   |
| Auxiliary Pump Low<br>Pressure Line Filter                    | 214    | Element plugs.                  | 26                  | ,   | 3               |       | 1                |        |
| Pressure Dine Filter  |        | Element ruptures,               | 27                  |   | 3               |       | 0                |        |
| Low Pressure Relief<br>Valve                                  | 215    | Fails open.                     | 28                  | Redundant with find number 216 valve.         | 0               |       | 1                |        |
|   |        | Fails closed.                   | 29                  |   | 0               |       | 1                |        |
| Low Pressure Over-<br>poard Drain Relief                      | 216    | Fails open.                     | 30                  | Redundant with find number 215 valve.         | 0               |       | 1                |        |
| Valve   |        | Fails closed                    | 31                  |   | n               |       | 1                |        |
| Low Pressure Ground<br>Service Disconnect                     | 217    | Ruptures or leaks excessively.  | 32                  |   | 3               |       | 0                |        |
| High Pressure Ground<br>Service Disconnect and<br>Check Valve | 218    | Fails open in combin-<br>ation, | 33                  | Disconnect and valve are redundant in flight. | 3               |       | 0                |        |
| ⊘песк <b>v</b> ајуе   |        | Fails closed (valve only).      | 34                  | ing   | o o             |       | 0                |        |
| S-IV B STAGE HYD  | RAUI   | JC SYSTEM RELIABIL              | TY                  | 9939  |                 |       |                  |        |



ESNFIDENTIAL

Figure 11. Simplified schematic for engine tank and

propellant feed system for S-II and S-IV B

#### Table 10.

FAILURE ANALYSIS CHART (SHORT FORM) FOR: S-II and S-IV B Stages of Saturn V Vehicle

SYSTEM: Tank and Propellant for J-2 Engine

#### STATE-OF-THE-ART RELIABILITY ESTIMATE

| COMPONENT   | Z n            | COMPONENT FAILURE MC      |                     | EFFECT OF COMPONENT<br>FAILURE MODE              |                    |        | E PRO<br>IGNAE<br>I OPER<br>PHAS | T 3J   | 0         |
|---|----------------|---------------------------|---------------------|--|--------------------|--------|----------------------------------|--------|-----------|
|   | NUMBER<br>FIND |                           | REFERENCE<br>NUMBER |  | P<br>Chill<br>Down | START  |                                  | SF     | TUI       |
| GO <sub>Z</sub> Diffuser  | 60             | Clogg, contamination.     |                     |  | 0                  | 0      | 1                                | 0<br>0 | S-1V<br>0 |
| LO <sub>2</sub> Tank vent valves(2)   | 61             | Fails closed              |                     | Redundant. Slow leak, possible performance loss. | 0                  | 0      | 0<br>1                           | 0      | 0         |
| LO <sub>2</sub> Tank Pressuriza-<br>tion solenoid valve.                            | 62             | Fails open.               |                     | Lack of pressuriza-<br>tion.                     | 3                  | 1<br>I | 1                                | 0      | 1         |
| LO, Insert. Disconnect Fill Drain & Purge.  | 63             | Fails closed Leaks,       |                     | Loss of tank purge.                              | 0                  | 0      | 1                                | 0      | 0         |
| GH <sub>2</sub> Diffuser.   | 64             | Clogg, contain.           |                     |  | 0                  | 0      | 1                                | 0      | 0         |
| LH <sub>2</sub> Tank Vent Valves<br>(2)   | 65             | Fails closed. Fails open. |                     | Redundant. Slow leak, possible performance loss. | 0                  | 0      | 1                                | 0      | 0         |
| LH2 Tank Pressuriza-<br>tion solenoid valve.  | 66             | Fails open.               |                     | Lack of pressurization                           | 3                  | 1      | 1                                | 0      | 1         |
| LH <sub>2</sub> Inserting Discon-<br>nect, Fill Drain and<br>Purge,                 | 67             | Leaks.                    |                     | Loss of tank purge.                              | 0                  | 0      | 1                                | 0      | 0         |
| Helium Receiver Tanks, fill and disconnects (2).                                    | 68             | Leaks.                    |                     | Loss of tank pressure                            | 0                  | 0      | 1                                | 0      | 0         |
| He Check Valves   | 69             | Leaks.                    |                     | Loss of tankpressure                             | 0                  | 0      | 1                                | 0      | 0         |
| Emergency Shutoff<br>valves - 2 per engine.<br>(LO <sub>2</sub> , LH <sub>2</sub> ) | 21,<br>31      | (Included with engines)   |                     |  |                    |        |                                  |        |           |
|   |                |                           |                     | p, TOTAL = P <sub>T</sub> = .9972,               | 1                  | 4      | 12                               | 0      | 4         |
|   |                |                           |                     | P <sub>T</sub> = .9940,                          | wo starts          |        |                                  |        |           |






Figure 12. Reliability curves of S-I and S-II stages, engine cluster with five engines, four with TVC

# SECTION IV SUMMARY OF RELIABILITY ESTIMATES

#### STATE-OF-ART RELIABILITY ESTIMATE

The following listing is a summary of the reliability estimates for the various equipment systems associated with the Saturn V propulsion systems.

- 1. F-1 Engine Reliability (with hold-down) is . 9902.
- 2. F-1 Hydraulic (TVC) Reliability is . 9987.
- 3. S-IC Stage Fuel System Reliability is . 9956.
- 4. S-IC Stage Oxidizer System Reliability is . 9931.
- 5. S-IC Stage Control Pressure System Reliability is . 9981.
- 6. J-2 Engine Reliability for one (in Flight) start is . 9782.
- 7. J-2 TVC Reliability for one start is . 9970.
- 8. J-2 TVC Reliability for two starts is . 9936.
- 9. J-2 Tank System Reliability for one start is . 9972.
- 10. J-2 Tank System Reliability for two starts is . 9940,
- 11. The S-IC Stage Reliability for five engines, four TVCs, and supporting systems is .933 (for NEOC).
- 12. The S-IC Stage Reliability for same as item eleven above, but for SEOC is . 969 (Isolation factor = 75%).
- 13. The S-II Stage Reliability for five engines, four TVCs and supporting systems for one start is .880 (for NEOC).
- 14. The S-II Stage Reliability for same as item thirteen above, but for SEOC is .970 (Isolation factor = 75%).
- 15. The S-IVB Engine Reliability, one engine for one restart is .9522.
- 16. The S-IVB Propulsion Stage Reliability, one engine, one TVC (Hydraulic), and one tank system, for one restart (two starts) is .938.





## SATURN V PROPULSION SYSTEM RELIABILITY ESTIMATE CALCULATIONS

The following is a brief summary of some of the calculated results of this study, based on the mathematical techniques presented in TEMPO report RM 63TMP-24 relating to the Saturn I revised propulsion system reliability analysis. <sup>3</sup> Refer to the List of Symbols on the last page of this section for definition of symbols used in this summary.

Simplified S-II and S-IVB Engine Tanks and Propellant Feed System

$$q_{T1} = 12$$
 (chill down);  $q_{T2}^* = 0$ 

$$q_{T2} = 4 \text{ (start)}; q_{T2}^* = 0$$

$$q_{T3} = 12 \text{ (run)}; q_{T3}^* = 0$$

$$q_{T4} = 0$$
 (stop);  $q_{T5}^* = 0$ 

hence for the S-II stages,

$$\overline{q}_{TO} = (12 + 16) = 28$$

 $\bar{P}_{TO}$  = .9972; Reliability of tank system for one in-flight start,

and for the S-IVB stage,

$$\overline{q}_{TO} = (12 + 20 + 12 + 16) = 60$$

 $\overline{P}_{TO}$  = .9940; Reliability of tank system for two in-flight starts.

S-II Propulsion System Reliability

With five J-2 engines, 1 tank system, 4 TVCs.

1. No Engine Out Capability (N.E.O.C.)

a. Single Engine Reliability

$$q_{e0} = (q_{e1} + q_{e2} + q_{e3} + q_{e4})$$
 (1)

q<sub>el</sub> = (4 + 8) = 12, chill down (first figure in parenthesis is the catastrophic failure mode)

$$q_{el}^* = 4$$





$$q_{e2} = (5 + 79) = 84$$
, start
 $q_{e2}^* = 5$ 
 $q_{e3} = (27 + 88) = 115$ , run
 $q_{e3}^* = 27$ 
 $q_{e4} = (0 + 7) = 7$ , stop
 $q_{e4}^* = 0$ 

therefore,

q<sub>e0</sub> = 218; p<sub>e0</sub> = .9782, Single engine reliability for all failures

q\* = 36; p\* = .9964, Single engine reliability against catastrophic failure

### b. Cluster of Five Engines

With 4 TVCs single TVC estimated reliability for S-II stage is:

$$P_{v} = .9970 ; q_{v} = 30$$

$$\overline{P}_{5,4} \begin{pmatrix} 0 \\ 0 \end{pmatrix} = 1 - (q_{e0} + q_{v})^{4} (1 - q_{e0})$$

$$= \left[1 - (218 + 30)\right]^{4} (.9782)$$
(2)

hence,

$$P_{5,4} \begin{pmatrix} 0 \\ 0 \end{pmatrix} = .890$$
, for S-II propulsion (less tanks).

## c. Cluster of Five Engines and Engine Shutdown (S.S.D.) Capability

Of the 36 failures resulting in catastrophic failures, it is assumed that about half of these could be reduced to safe shutdown of engine, if sensor system were used. Thus, the isolation factor is estimated to be:

$$I_{\mathbf{F}} \approx \left( \frac{q_{\mathbf{e}0} - .50 \ q_{\mathbf{e}0}^*}{q_{\mathbf{e}0} + .50 \ q_{\mathbf{e}0}^*} \right)$$

$$= (200/236) = .85$$
(3)





l) For  $I_F = .85$ , Engine and TVC cluster reliability for safe shutdown, (but not S.E.O.C.) is:

$$\overline{P}_{5,4}$$
  $\begin{pmatrix} 1\\1 \end{pmatrix}$  = .9720, for S.S.D., Engines and TVC.

2) Propulsion System, S-II S.S.D. reliability including tank system is:

$$R_p = (.972) (.9972) = .9692$$

which permits alternate mission, safety, etc.

3) Propulsion System, S-II, mission success reliability is:

$$R_P = (.890) (.9972) = .8880 (N.E.O.C.)$$

and

 $R_{\mathbf{P}}^* = (.9964)^5 = .9822$  (N. E. O. C.) reliability of engine cluster against catastrophic failure.

2. Single Engine and Single TVC Out Capability

Numerically, this is the same as  $R_{\mathbf{p}}^{*}$  for S.S.D., thus, the cluster propulsion reliability for mission success is:

$$R_{p} = .970 (S.E.O.C.)$$
.

S-IVB Propulsion System Reliability

1. One-J-2 Engine and One-TVC; for one restart (two starts).

$$q_{e0} = (2q_{e1} + 2q_{e2} + 2q_{e3} + q_{e5} + q_{e4})$$
 (4)

where

$$q_{e5} = (4 + 45) = 49$$
 (shutdown, restart required)

$$q_{e0} = 478$$
 and  $q_{e0}^* = 76$ 

$$p_{e0} = .9522, p_{e0}^* .9924$$
.

2. S-IVB "TVC" system reliability was calculated for two complete runs and a coasting period:

$$p_{xx} = .9939$$



3. The S-IVB engine tank and propellant feed system reliability estimates for the two chill downs, two starts, two runs, one shutdown and one stop is:

$$q_{T} = .9940.$$

4. The total S-IVB propulsion stage reliability for the engine, TVC, tank and feed system is:

$$P_{1,1} = (.9522) (.9939) (.9940) = .938.$$



#### LIST OF SYMBOLS

| $P_{e0}$                             | Total engine reliability   |
|--------------------------------------|--|
| P <sub>el</sub>                      | Engine reliability, during chill down  |
| P <sub>e2</sub>                      | Engine reliability, during start   |
| P <sub>e3</sub>                      | Engine reliability, during run   |
| $P_{e4}$                             | Engine reliability, at stop (no restart capability)  |
| p <sub>e5</sub>                      | Engine reliability, at shutdown (for restart capability)   |
| q                                    | Engine unreliability, (probability of failure, usually given in ten thousandths)   |
| p*                                   | Reliability in catastrophic failure mode ( $p = 1 - q \times 10^{-4}$ )  |
| рто                                  | Total tank system reliability, etc.  |
| 10                                   |  |
| N.E.O.C.                             | No engine out capability   |
|                                      | No engine out capability Single engine out capability  |
| N.E.O.C.                             |  |
| N.E.O.C.<br>S.E.O.C.                 | Single engine out capability   |
| N.E.O.C.<br>S.E.O.C.<br>S.S.D.       | Single engine out capability  Safe engine shutdown   |
| N.E.O.C.<br>S.E.O.C.<br>S.S.D.       | Single engine out capability  Safe engine shutdown  Sensor reliability, all failure modes  |
| N.E.O.C. S.E.O.C. S.S.D. S           | Single engine out capability  Safe engine shutdown  Sensor reliability, all failure modes  (1-G) probability of shutting down good engine  |
| N.E.O.C. S.E.O.C. S.S.D. S G S G O O | Single engine out capability  Safe engine shutdown  Sensor reliability, all failure modes  (1-G <sub>o</sub> ) probability of shutting down good engine  (1-G <sub>S</sub> ) probability of not shutting down good engine  |
| N.E.O.C. S.E.O.C. S.S.D. S G G       | Single engine out capability  Safe engine shutdown  Sensor reliability, all failure modes  (I - G <sub>O</sub> ) probability of shutting down good engine  (I - G <sub>S</sub> ) probability of not shutting down good engine  Probability of shutting down a bad engine |

Cluster reliability for m engines, n TVCs and one out capability for each

 $I_{\hbox{\scriptsize E}}$  Isolation factor for engine

 $I_{V}$  Isolation factor for TVC system.



#### REFERENCES

- 1. North American Aviation, Inc., Rocketdyne Division. H-1
  Engine Reliability Status: Catalogued as General Electric
  Company, TEMPO, TMP-13820. (CONFIDENTIAL).
- 2. North American Aviation, Inc., Rocketdyne Division. Engine
  Test Stand Data, REM-1181-1544, p 4. June 1961.
- 3. General Electric Company, TEMPO. Saturn I Revised Propulsion System Reliability Analysis, RM 63TMP-24. Santa Barbara, California: April 1963.



#### **BIBLIOGRAPHY**

- 1. North American Aviation, Inc., Rocketdyne Division. Preliminary
  Engine Data, Rocket Engine Model J-2, R-2825-1. Los Angeles,
  Calif.: 18 April 1963 (CONFIDENTIAL).
- 2. North American Aviation, Inc., Rocketdyne Division. F-1

  Design Information, R-2823-1. 23 August 1961 (CONFIDENTIAL).
- 3. North American Aviation, Inc., Rocketdyne Division. Failure Effect Analysis, F-1 Engine Subsystem, RAR-2181-1503.
- 4. North American Aviation, Inc., Rocketdyne Division. Failure Effect Analysis, J-2 Engine Subsystem, RAR-2181-1504.
- 5. North American Aviation, Inc., Space and Systems Division.

  Saturn S-11 General Manual, NASA Support Document, SM-S11-01. 1 April 1963.
- 6. Douglas Aircraft Company, Inc., Missile and Space Systems
  Division. Reliability Mathematical Model Saturn S-IVB Stage,
  SM-43610. Culver City, Calif.: 15 April 1963.
- 7. Douglas Aircraft Company, Inc., Missile and Space Systems
  Division. Model Specification, Saturn S-IVB Stage, DS-2163.
  15 February 1963 (CONFIDENTIAL).
- 8. Marshall Space Flight Center. <u>Saturn S-IC Stage Systems</u>. Huntsville, Ala.: Received May 1963 (CONFIDENTIAL).
- 9. Marshall Space Flight Center. Saturn V Project Development Plan. 1 April 1963 (CONFIDENTIAL).
- 10. General Electric Company, TEMPO. Reliability Growth, for
  Liquid and Solid Rocket Single and Clustered Stages: Material
  integrated into a study for the Large Launch Vehicle Program
  Group, (LLVPG). November 1961 (SECRET).

